



### Safety Hoist

Use the Dual Drive winch (Manual or Drill Drive) to safely and rapidly lift up to 75 lbs to the deck. Features patented safety **overload protecting** auto-brake winch system. Unit includes bucket harness. (bucket not included)

# Accessorize Your Tele-Tower® Adjustable Work Platform



### Large Tray

Use one or both of the tool trays to keep tools at hand and off the deck.



### Small Tray



**Reduction Drive** Is an add-on to the Tele-Tower® that makes it easier to raise and lower the Tele-Tower®. Great for when you have an extension unit installed.




### Ground Drive

- Stay productively on the deck & move the Tele-Tower® around the job with this attachment.
- Automatically adjusts with the Tele-Tower® for deck heights from 6' to 11'
- Fits Tele-Tower® Models:  
1101  
1101-96  
1101-22  
1101-2296  
(not for use with installed extension unit)

### Extensions

Height extensions for both the Tele-Tower® model 1101 & 1101-96. Fasten to the top of the Tele-Tower® and add 6.5 feet to the height. With the extension on the Tele-Tower® is adjustable from 12.5 feet to 17.5 feet in 6 inch increments.



### Safety Rail Storage Cradle

Holds all four safety rails securely under your deck. Keeps the rails close at hand when not in use.

The Storage Kit is excellent for keeping your Tele-Tower® in a nice compact space. It keeps the unit all together in a smaller foot print. It will also hold the extension.






## Tele-Tower® Connector

Joins multiple Tele-Tower®s together at the base and the deck, allowing you to create a long working platform. Caution must be used when adjusting heights of the multiple Tele-Tower®s joined by the Connector. Each Tele-Tower® must be adjusted individually and the deck connector will need to be repositioned after adjusting. All Tele-Tower®s need to be adjusted to the same height when using the Connector. End Chains must be used to connect the two guardrails on either end. Add the 14-07 Tele-Rail to add guard rails between two Tele-Tower® units spanning a bus or vehicle.



## Safety Pole

Use to secure the end chains when working against a wall and not using the guardrails on the wall side. These are sold individually and two are required on a Tele-Tower®.



## Got a custom application or need?

Give us a call or email us with all of the details and let us see what we can do for you.

1-800-448-0822

telpromktg@telproinc.com